
Guidelines for Cleaning the U.are.U Sensor

Depending on the amount of use, the sensor window may need to be cleaned from time to time. It will pick up dirt and salts from your finger that may cause the window to become cloudy.

Recommended Cleaning

To remove dust and dirt, apply the sticky side of a piece of adhesive cellophane tape on the window and peel it away. To remove grease, gently wipe the window with a clean, soft cloth that is dampened with a mild ammonia-based glass cleaner.

Cleaning Precautions

Never clean the sensor window with paper. Do not submerge the sensor in liquid or pour liquid directly on the sensor window.

